


ECHOMETER ACOUSTIC WELLHEAD PARTS LIST

Part Number	Part Name	Picture
0900GG	O'Ring Kit (Gas Gun)	
0900QL	O'Ring Kit (.45 Calibre)	
0900TN	O'Ring Kit (Ten Gauge)	
0900WG	O'Ring Kit (Remote Fire)	
3031Kit	Hose End Repair Kit	
GG0220	Filler Bleed Chamber Valve	
GG0220P	Filler Bleed Chamber Valve Pin	
GG1200	Transducer Connector 3/8"	
GG1250	Trigger Pawl Assembly	
GG2000	Valve Cover or Cap for Quick Connector	
GG2040	Valve Core or Valve Stem (High Pressure)	
GG2050	Valve Body	

GG2060

BNC Connector (GG, RE)



GG2070

BNC 90 Degree Connector



GG2080

Cocking Arm



GG2090

Pressure Gauge (200-1500 PSI)



GG2100

Cap Screw



GG2110

Housing Cap



GG2130

Stop Pin



GG2170

Casing Bleed Valve



GG2190

Cocking Arm Spring



GG2200

Microphone Electric Tube



GG2210

Casing Bleed Tube



GG2230

Gas Valve (GG)



GG2250

Gas Gun Housing



GG2290

Microphone - Rebuilt (GG, WG)



GG2290

Microphone - Thermal, Rebuilt




GG2300

Microphone - Brand New (GG, WG)



GG3490

Mic Electric Wire W/Pin



GG4900

Microphone Protector



IG0100

Volumn Chamber (5K)



IG2000

Pressure Gauge (6000 PSI)



IG3600

Transducer Connector 3/8"



TN1040

BNC Connector (TN)



TN1450

BNC Cap & Chain



WA4750

BNC Jack to Jack



WG1100

Bleed Valve



WG1200

Transducer Connector 1/2"



WG1500

Orifice - RF150



WG1550

Orifice Housing



WG1800

Gas Valve (WG)



WG2300

Plunger Spring



WG2400

Plunger Housing (WG)



WG2700

Solenoid Nut



WG3400

Volume Chamber



WG4050

Coil Housing Solenoid Complete



WG4770

Restrictor



WG5000

Dart Valve Seat



WG5200

BNC Connector (QL, WG, IG)



WG5300

Dart Valve



WG8800

Plungerlift Adapter (2" to 1/2")

